




SELF MEASUREMENT GUIDE

STRUCTURAL JACKET
J401-GLD



FOLLOW THE MEASUREMENT GUIDE BELOW TO DETERMINE YOUR GARMENT SIZE

A - Measure your chest circumference directly under your arms

B - Measure your back length down the centre of your back, starting at the base of your neck and finishing level with your knuckles (your arms should be resting at the sides of your body)

All measurements are in CM

REGULAR	XS	S	M	L	XL	2XL	3XL	4XL
A - Chest	93-98	98-103	103-108	108-113	113-118	118-123	123-128	128-133
B - Back Length	81-82	82-83	83-84	84-85	85-86	86-87	87-88	88-89

SHORT	XS	S	M	L	XL	2XL	3XL	4XL
A - Chest	93-98	98-103	103-108	108-113	113-118	118-123	123-128	128-133
B - Back Length	77-78	78-79	79-80	80-81	81-82	82-83	83-84	84-85

LONG	XS	S	M	L	XL	2XL	3XL	4XL
A - Chest	93-98	98-103	103-108	108-113	113-118	118-123	123-128	128-133
B - Back Length	85-86	86-87	87-88	88-89	89-90	90-91	91-92	92-93